



## PERCPAD / SAMPLEPAD

### 内蔵サウンドリスト

Num	Name	Midi Note	Num	Name	Midi Note
1	CLAP	39	14	LIVE SHAKER	69
2	FINGER SNAP	70	15	E TOM HEX	48
3	COWBELL HIGH	76	16	TIMBALE	65
4	COWBELL LOW	56	17	CONGA SLAP	62
5	TRIANGLE MUTED	80	18	CONGA OPEN	63
6	TRIANGLE OPEN	81	19	E KICK 8	36
7	TAMBOURINE	54	20	E KICK 9	36
8	WIND CHIMES	72	21	E KICK HEX	36
9	SLEIGHBELLS	71	22	E SNARE 8	38
10	CLAVES	75	23	E SNARE 9	38
11	BLOCK	77	24	E SNARE HEX	38
12	JAWBONE	58	25	E CRACK HEX	44
13	STUDIO SHAKER	70			